

PC Tool

 **Installation and operating instructions**

CONTENTS

	Page
1. PC Tool	3
2. Introduction	4
Requirements	
Configuring the PC tool	
Configuring a modem connection	
Connecting to a unit	
Establishing a direct connection via PC Tool link	
Establishing a direct connection via G100 gateway	
Establishing a modem connection via G100 gateway	
Establishing a connection chosen from telephone book	
Unit not responding	
Disconnecting and reconnecting	
Using the tool	
User interface overview	
Navigation with keyboard	
Monitor	
Monitor	
System overview	
Unit overview	
Alarm log	
Min./max. log	
Summation counters	
Commands	
Edit & view settings	
Edit & view settings	
Basic settings	
Trip & warning settings	
Trip counters	
Save settings	
Saving a standard configuration	
Loading a standard configuration	
My installations	
My installations	
Managing installations	
Managing units	
My standard configurations	
My standard configurations	
Importing a standard configuration	
Exporting a standard configuration	
CU 3	
CU 3 max. current configuration	
Adjusting time in the CU 3	

1. PC Tool

Version: V.02




2. Introduction

The Grundfos PC Tool MP 204 is a management and service tool for MP 204 and CU 3 motor protectors.

The tool can be used for on-site service as well as for verification and management.

Click **Help > About** in the menu bar to see the current version of the PC tool.



This manual covers the general aspects of using the PC tool. It provides no information on specific application topics.

2.1 Requirements

Processor	Pentium III 900MHz or higher
RAM	Min. 256 MB
Free hard disc space	Min. 300 MB
Operating system	Microsoft Windows 2000 SP4 or later. Only US versions guaranteed.
Monitor resolution	1024 x 768 pixels*)
Peripherals	CD-ROM drive. Mouse or other pointing device. RS-232 serial port.
Other requirements	PC Tool Link or G100 gateway

*) Recommended

3. Configuring the PC tool

A direct connection and/or modem connection can be configured, depending on how you want to communicate with the unit.

3.1 Configuring a modem connection

Before configuring a modem connection, set up the modem in the Windows environment. In most cases, the modem is set up via 'plug and play'. For further information, consult the modem manual.

To configure the modem connection, click **Tools > Options** and select the **Modems** tab.



The **Modems** window opens.


The left window displays all unassigned modems.

The right window displays all assigned PC tool modem ports.

The first time the **Modems** window is opened, the PC tool modem ports window is empty.

Use the left/right arrow to add/remove a modem connection for the PC tool.

When you have selected a modem connection, click [**Apply**] and/or [**OK**].



It is possible to assign multiple modem connections. The assigned modems will be displayed in a selection box when you try to establish a modem connection to a unit. The order in which the modems appear in the selection box can be controlled with the up and down arrows.

If no modems appear in the list, you have to configure a modem in the Windows environment.

4. Connecting to a unit

Note: If two or more units are connected to the same Grundfos GENIbus, each unit must have a unique GENIbus address assigned, for example with the Grundfos R100 remote control.

Connection to a unit can be made in four different ways:

- Direct connection via PC Tool link
- Direct connection via G100 gateway
- Modem connection via G100 gateway
- Connection chosen from telephone book.

The direct connection is mainly for on-site service and management.

The modem connection is mainly for off-site service and management.


4.1 Establishing a direct connection via PC Tool link

If you want to use the direct connection, your PC must have a free serial port (RS-232) and a PC Tool Link kit. Connect the cables before turning on your PC.


Turn on your PC. To start the PC tool, click **Start > All Programs > Grundfos PC Tools > PC Tool MP 204**.




When the PC tool starts up, a **Select connection mode** dialog box appears. To establish a direct connection, select **Serial GENI connection**. Click [OK] or press [Enter].



If two or more COM ports are available, a selection box appears. Select the COM port to which the PC Tool link is connected.



During the connecting process, status information will be displayed.



When the connection has been established, the On-line icon appears in the lower right corner.



When the connection has been established, the PC tool opens the start window. The PC tool is ready for use.

4.2 Establishing a direct connection via G100 gateway


Turn on your PC. To start the PC tool, click **Start > All Programs > Grundfos PC Tools > PC Tool MP 204**.




When the PC tool starts up, a **Select connection mode** dialog box appears. To establish a direct connection, select **Serial G100 connection** and select connection speed in the drop-down box. Click [OK] or press [Enter].



If two or more COM ports are available, a selection box appears. Select the COM port to which the PC Tool link is connected.



During the connecting process, status information will be displayed.



When the connection has been established, the On-line icon appears in the lower right corner.



When the connection has been established, the PC tool opens the start window. The PC tool is ready for use.

4.3 Establishing a modem connection via G100 gateway


It is only possible to establish a modem connection to a unit with a modem.

If you use an external modem, connect it to your PC.



Turn on your PC. To start the PC tool, click **Start > All Programs > Grundfos PC Tools > PC Tool MP 204**.



When the PC tool starts up, a **Select connection mode** dialog box appears. To establish a modem connection, select **Modem G100 connection** and enter the telephone number. Click [OK] or press [Enter].




During the connecting process, status information will be displayed.



When the connection has been established, the On-line icon appears in the lower right corner.



If the connection attempt fails, an error message appears. Before you try to reconnect, check the modem connection.



When the connection has been established, the PC tool opens the start window. The PC tool is ready for use.


4.4 Establishing a connection chosen from telephone book

If you use an external modem, connect it to your PC.

Turn on your PC. To start the PC tool, click **Start > All Programs > Grundfos PC Tools > PC Tool MP 204**.



When the PC tool starts up, a **Select connection mode** dialog box appears. To establish a connection, select **Choose from telephone book** and select installation name in the drop-down window. Click [OK] or press [Enter].



During the connecting process, status information will be displayed.



Scanning for devices ...

When the connection has been established, the On-line icon appears in the lower right corner.




When the connection has been established, the PC tool opens the start window. The PC tool is ready for use.



4.5 Unit not responding

If a unit is not responding or missing, the unit icon has an "X" across it and turns grey.

A new unconfigured unit will have the name “-”.



4.6 Disconnecting and reconnecting

When you are on-line with a unit and want to disconnect, click the disconnect icon.



When the PC tool is disconnected from the unit, the On-line indication in the lower right corner changes to Off-line.



To reconnect the unit, click the connect icon.



When the icon is clicked, the connection dialog box appears. The connect and disconnect icons can be clicked at any time.

5. Using the tool

This section describes how to use the PC tool. The description starts with a general overview, followed by a description of each of the PC tool main functions (user functions).

5.1 User interface overview

The user interface is divided into four main sections:

5.1.1 Menu and tool bars

The menu and tool bars change according to the selected user task.

5.1.2 Task bar


The task bar comprises all supported user tasks or user functions.

5.1.3 Work area

The work area is the area where the user function works.

5.1.4 Status bar

The status bar displays status information and messages about current activities.



5.2 Navigation with keyboard

ALT + UP / ALT + DOWN: Navigates up and down in the task bar.

TAB / SHIFT + TAB: Moves cursor to next/previous position.

In the **Monitor** and **Edit & view settings** windows:

CTRL + TAB / CTRL + SHIFT + TAB: Moves between units.

ALT + LEFT / ALT + RIGHT: Moves between sub tasks (arrows).

6. Monitor

6.1 Monitor


You can choose to monitor

- the **System**, which gives a system overview with key values of each connected unit, or
- a specific unit, which gives a detailed overview with all values of the unit.

The monitor function also allows you to view logs.

Although the monitor shows real-time data, there will be some delay in responding to commands and from data shown in the unit.

In the unit selection bar, you can select **System**, **1**, **2**, etc. The number below the icon is the R100 unit number.



In the navigation bar, you can select **Overview**, **Alarm log**, **Min./max. log**, **Summation counters** or **Commands** depending whether **System** or a *unit* is selected. Each view gives you detailed information on the selected item. Each view is described in the following sections.

6.2 System overview

The **Overview** displays the current status and key values of all connected units.

Symbols indicating the current status of the units:

Symbol	Description
	Running



Running, but with warning



Tripped

If a unit has tripped, a red icon appears at the tripped unit.



6.3 Unit overview

The unit overview is divided into four sections.

The **Status** section displays all status values of the unit.

The **Active alarms & warnings** section shows current alarms and warnings.

Note: The alarms and warnings are not indicated in the order of occurrence.

The number in brackets is the alarm or warning code shown in the display of the unit.

Monitor

System 1 2

Overview

Alarm log

Min/max log

Summation counters

Commands

Data item	Value	Unit
Operating mode	Tripped	
System mode	Running	
Trip relay	Open	
Signal relay	Closed	
Power	0	W
Current L1	0.0	A
Current L2	0.0	A
Current L3	0.0	A
Current, average	0.0	A

Active alarms & warnings

- Current overload (48)
- Undervoltage (40)
- Current overload (48)

Restart Test trip

Symbols for Active alarms & warnings:

Symbol	Description
	Alarm
	Warning

The **Graphical** section displays the current status of the pumps.

Monitor

System 1 2

Overview

Alarm log

Min/max log

Summation counters

Commands

Data item	Value	Unit
Operating mode	Tripped	
System mode	Running	
Trip relay	Open	
Signal relay	Closed	
Power	0	W
Current L1	0.0	A
Current L2	0.0	A
Current L3	0.0	A
Current, average	0.0	A

Active alarms & warnings

- Current overload (48)
- Undervoltage (40)
- Current overload (48)

Restart Test trip

The **Control** section allows you to [Restart] the unit or to run the [Test trip] function.

Monitor

System 1 2

Overview

Alarm log

Min/max log

Summation counters

Commands

Data item	Value	Unit
Operating mode	Tripped	
System mode	Running	
Trip relay	Open	
Signal relay	Closed	
Power	0	W
Current L1	0.0	A
Current L2	0.0	A
Current L3	0.0	A
Current, average	0.0	A

Active alarms & warnings

- Current overload (48)
- Undervoltage (40)
- Current overload (48)

Restart Test trip

The [Test trip] function tests the alarm and trip relays. The alarm message **Commanded trip (18)** appears in the **Active alarms & warnings** section.

Active alarms & warnings

Commanded trip (18)

6.4 Alarm log

The **Alarm log** view displays the latest five alarms logged by the unit. To clear the log, click [**Reset alarm log**].

The time displayed to the right indicates the time which has passed since the MP 204 tripped.

Note: The time is measured only as long as the MP 204 is powered. The clock stops when the MP 204 is no longer powered.

Alarm Log

1 Missing phase (2)	30:54
2 Missing phase (2)	30:54
3 Missing phase (2)	32:20
4 Undervoltage (40)	53:55
5 Undervoltage (40)	53:56

Reset alarm log

Overview

Alarm log

Min/max log


Summation counters

Commands

6.5 Min./max. log

The **Min./max. log** displays maximum and minimum values. To

clear the log, click [Reset min./max. log].




[Reverse phase sequence] reverses the phase sequence. See Unit overview.

[Activate learning] reactivates the learning process.


[Factory preset] resets the unit to factory settings.

[Power on reset] restarts the unit, i.e. same as disconnecting and reconnecting power supply.




6.6 Summation counters

The **Summation counters** view gives an overview of counters. It is possible to preset or reset a **Trip counter** in the **Edit & view settings** window. The other counters are cumulative and cannot be reset.



To clear the **Auto restart counter**, click [Reset auto restart counter].



6.7 Commands

To activate a function in the unit, click the appropriate button.


7. Edit & view settings

7.1 Edit & view settings


To change unit settings, click **Edit & view settings**.




When the PC tool is reading data from the units, a progress bar appears.



In the toolbar, you can click the **Disconnect**, **Reload**, **Undo** or **View report** icons.



In the main window, select the unit to be set.



Use the navigation bar to select

Basic settings

Trip & warning settings

Trip counters


Save settings

Each view is described in the following sections.

7.2 Basic settings

The changes are not saved to the unit until you click the **Save settings** icon.

Use the up and down arrows to change the values,




or enter a value directly in the field.



If you enter an invalid value, the field turns red and you cannot save the changes to the unit.



To change the setting in a drop-down box, click the arrow. Then you will get a list of options. Select the appropriate option.



A dimmed grey box indicates that the box and data values are disabled due to another setting that automatically disables the box and data values.

Basic settings	
Nominal voltage	230.0
Mains connection	1 phase
Trip class (IEC)	45
Trip delay (IEC)	10.0
Trip delays (except IEC)	10
Power on delay	5
Restarting	Automatic
Auto restarting time	300
Current transformation factor	No transformation

To disable a trip and warning function, remove the check mark.
The text and value fields are dimmed grey.

Trip & warning settings	Trip lim.	Warning lim.	Auto restart
<input type="checkbox"/> Overvoltage	20 <input type="button" value="+"/> %	15 <input type="button" value="+"/> %	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Undervoltage	20 <input type="button" value="-"/> %	15 <input type="button" value="-"/> %	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Current overload	1.0 <input type="button" value="-"/> A	0.9 <input type="button" value="-"/> A	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Current underrload	40 <input type="button" value="-"/> %	35 <input type="button" value="-"/> %	<input checked="" type="checkbox"/>

If you enter contradictory values, the field turns yellow, but you can still save the changes to the unit. This is useful if, for instance, you want the unit to trip without any warning.

Trip & warning settings	Trip lim.	Warning lim.	Auto rest.
<input checked="" type="checkbox"/> Overvoltage	20 <input type="button" value="↓"/> %	25 <input type="button" value="↓"/> %	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Undervoltage	20 <input type="button" value="↓"/> %	15 <input type="button" value="↓"/> %	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Current overload	1.0 <input type="button" value="↓"/> A	0.9 <input type="button" value="↓"/> A	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/> Current underrload	40 <input type="button" value="↓"/> %	39 <input type="button" value="↓"/> %	<input checked="" type="checkbox"/>

A check mark enables a function.

Present sensors	
Pt sensor present	<input checked="" type="checkbox"/>
Tempcon sensor present	<input type="checkbox"/>
Display options	
Unit system	SI <input type="button" value="▼"/>
Primary status value	Line current <input type="button" value="▼"/>
Display warnings	<input type="checkbox"/>
Display cos phi	<input checked="" type="checkbox"/>

If you enter an invalid value, the field turns red and you cannot save the changes to the unit.

Trip 3: warning settings		Trip lim.	Warning lim.	Auto restart
<input checked="" type="checkbox"/>	Overtoltage	20 <input type="button" value="↓"/> %	40 <input type="button" value="↓"/> %	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>	Undervoltage	20 <input type="button" value="↓"/> %	15 <input type="button" value="↓"/> %	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>	Current overload	1.0 <input type="button" value="↓"/> A	0.9 <input type="button" value="↓"/> A	<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>	Current underrload	40 <input type="button" value="↓"/> %	39 <input type="button" value="↓"/> %	<input checked="" type="checkbox"/>

If the check box is empty, the function is disabled.

The screenshot shows the 'Present sensors' section of a configuration interface. It includes two checkboxes: 'Pt sensor present' (unchecked) and 'Tempco sensor present' (unchecked). A red box highlights the 'Pt sensor present' checkbox.

7.3 Trip & warning settings

To set trip and warning limits, select **Trip & warning settings**.

A check mark enables the trip and warning function.

Trip & warning settings		Trip lim.	Warning lim.	Auto restart
<input checked="" type="checkbox"/>	Oversupply	20 <input type="button" value="±"/>	% 15 <input type="button" value="±"/>	% <input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>	Undersupply	20 <input type="button" value="±"/>	% 15 <input type="button" value="±"/>	% <input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>	Current overload	1.0 <input type="button" value="±"/>	A 0.9 <input type="button" value="±"/>	A <input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>	Current underload	40 <input type="button" value="±"/>	% 39 <input type="button" value="±"/>	% <input checked="" type="checkbox"/>



To preset a counter, write-enable the field by putting a check mark in the check box and enter a value.

Trip counters		
<input checked="" type="checkbox"/>	Operating time, trip counter	6000 <input type="button" value="▼"/> <input type="button" value="▲"/> min
<input type="checkbox"/>	Starts, trip counter	0 <input type="button" value="▼"/> <input type="button" value="▲"/>
<input type="checkbox"/>	Energy, trip counter	0 <input type="button" value="▼"/> <input type="button" value="▲"/> kWh

7.5 Save settings


To save your changes to the unit, click the **Save settings** icon.



A window shows the values that have been changed.

Changes:			
#	Data point	Original value	New value
2	Current overload trip limit	1.0	12.0
1	Nominal voltage	230.0	400.0

If no changes have been made or invalid values have been entered, the icon is dimmed grey.



To save the data to the unit, click [Save].



When the data has been saved successfully, a message box appears. Click [OK] to continue.




7.6 Saving a standard configuration

To save the current settings as a standard configuration for later use, click **Tools** and select **Save as standard configuration**.



Enter a **Name** and, if necessary, additional information in the **Notes** field. Click [OK].



A list of saved standard configurations can be found in **My standard configurations**.


7.7 Loading a standard configuration

To use a standard configuration, click **Tools** and select **Load standard configuration**.




Select template and click [OK].

Note: All current settings will be overwritten. To undo a loaded template, click the **Reload** icon.




When a standard configuration has been loaded, it will be indicated in the **Save settings** window.



To save the loaded configuration to the unit, click the **Save settings** icon.



To save the data to the unit, click [Save].



When the data has been saved successfully, a message box appears. Click [OK] to continue.




8. My installations

8.1 My installations

An installation is a named GENI network.

In the main window, you can add or modify an installation.


To add the current installation to **My installations**, click [**Create new**].



Enter a **Name**, select a **Phone** number, a **Connection method** and, if applicable, a **Baud rate**.


As additional information, you can enter a short description in the **Notes** field.

Click [**OK**].




8.2 Managing installations

To modify or delete an installation, right-click on the relevant installation and select **Modify installation** or **Delete installation**.



When you have modified the installation, click [**OK**].



8.3 Managing units

To modify a unit, change the position of the unit or delete a unit, right-click on the relevant unit and select

Modify unit – Modifies the settings of the unit.

Move unit up – Changes the position of the unit.


The top most unit will be shown as left most unit in the **Monitor** and **Edit & view settings** sections.

Move unit down – Changes the position of the unit.

Delete unit – Deletes the unit from the installation.



When you have modified the unit, click [OK].




9. My standard configurations

9.1 My standard configurations

A standard configuration is a template containing settings for a specific pump type, i.e. a pump with temperature sensor.


To view or modify a standard configuration, click **My standard configurations**. Select the configuration and click [Modify].

Modify the standard configuration as described in section **Edit & view settings**.




9.2 Importing a standard configuration

To import a standard configuration, right-click on an empty space and select **[Import standard configuration]**.




Browse to the file and select the file. Click [Open].




9.3 Exporting a standard configuration

To export a standard configuration, right-click the relevant configuration and select [Export standard configuration].



Browse to the folder where you want the configuration file to be saved and enter a name. Click [Save].




10. CU 3


10.1 CU 3 max. current configuration

To program the max. current limit, click Installation and select Max. current configuration....

Note: This must be done before programming current warning and current minimum limit.



Enter Max. current limit. Use the value from the motor nameplate. Click [Program].




10.2 Adjusting time in the CU 3

To adjust the time, click the clock icon.

Note: This function will not work with all versions of the G100.



Adjust time and date and click [Set].



Denmark GRUNDFOS DK A/S Martin Bachs Vej 3 DK-8850 Bjerringbro Tel.: +45-87 50 50 50 Telefax: +45-87 50 51 51 E-mail: info_GDK@grundfos.com www.grundfos.com/DK	France Pompes GRUNDFOS Distribution S.A. Parc d'Activités de Chesnes 57, rue de Malacombe F-38290 St. Quentin Fallavier (Lyon) Tél.: +33-4 74 82 15 15 Télecopie: +33-4 74 94 10 51	Mexico Bombas GRUNDFOS de Mexico S.A. de C.V. Boulevard TLC No. 15 Parque Industrial Stiva Aeropuerto Apodaca, N.L. 66600 Mexico Phone: +52-81-8144 4000 Telefax: +52-81-8144 4010	Thailand GRUNDFOS (Thailand) Ltd. 947/168 Moo 12, Bangna-Trad Rd., K.M. 3, Bangna, Phrakanong Bangkok 10260 Phone: +66-2-744 1785 ... 91 Telefax: +66-2-744 1775 ... 6
Argentina Bombas GRUNDFOS de Argentina S.A. Ruta Panamericana km. 37.500 Lote 34A 1619 - Garín Ccia. de Buenos Aires Phone: +54-3327 414 444 Telefax: +54-3327 411 111	Germany GRUNDFOS GMBH Schlüterstr. 33 40699 Erkrath Tel.: +49-(0) 211 929 69-0 Telefax: +49-(0) 211 929 69-3799 e-mail: infoserice@grundfos.de Service in Deutschland: e-mail: kundendienst@grundfos.de	Netherlands GRUNDFOS Nederland B.V. Postbus 104 NL-1380 AC Weesp Tel.: +31-294-492 211 Telefax: +31-294-492244/492299	Turkey GRUNDFOS POMPA San. ve Tic. Ltd. Sti. Gebze Organize Sanayi Bölgesi Ihsan dede Caddesi, 2. yol 200. Sokak No. 204 41490 Gebze/Kocaeli Phone: +90 - 262-679 7979 Telefax: +90 - 262-679 7905 E-mail: satis@grundfos.com
Australia GRUNDFOS Pumps Pty. Ltd. P.O. Box 2040 Regency Park South Australia 5942 Phone: +61-8-8461-4611 Telefax: +61-8-8340 0155	Greece GRUNDFOS Hellas A.E.B.E. 20th km. Athinon-Markopoulou Av. P.O. Box 71 GR-19002 Peania Phone: +0030-210-66 83 400 Telefax: +0030-210-66 46 273	New Zealand GRUNDFOS Pumps NZ Ltd. 17 Beatrice Tinsley Crescent North Harbour Industrial Estate Albany, Auckland Phone: +64-9-415 3240 Telefax: +64-9-415 3250	Ukraine ТОВ ГРУНДФОС Украина ул. Владимирская, 71, оф. 45 г. Киев, 01033, Украина, Тел. +380 44 289 4050 Факс +380 44 289 4139
Austria GRUNDFOS Pumpen Vertrieb Ges.m.b.H. Grundfosstraße 2 A-5082 Grödig/Salzburg Tel.: +43-6246-883-0 Telefax: +43-6246-883-30	Hong Kong GRUNDFOS Pumps (Hong Kong) Ltd. Unit 1, Ground floor Siu Wai Industrial Centre 29-33 Wing Hong Street & 68 King Lam Street, Cheung Sha Wan Kowloon Phone: +852-27861706/27861741 Telefax: +852-27858664	Norway GRUNDFOS Pumper A/S Strømsveien 344 Postboks 235, Leirdal N-1011 Oslo Tlf.: +47-22 90 47 00 Telefax: +47-22 32 21 50	United Arab Emirates GRUNDFOS Gulf Distribution P.O. Box 16768 Jebel Ali Free Zone Dubai Phone: +971-4- 8815 166 Telefax: +971-4-8815 136
Belgium N.V. GRUNDFOS Bellux S.A. Boomsesteenweg 81-83 B-2630 Aartselaar Tél.: +32-3-870 7300 Télécopie: +32-3-870 7301	Hungary GRUNDFOS Hungária Kft. Park u. 8 H-2045 Törökállint, Phone: +36-23 511 110 Telefax: +36-23 511 111	Poland GRUNDFOS Pompy Sp. z o.o. ul. Klonowa 23 Baranowo k. Poznania PL-62-011 Przeźmiero Phone: (+48-61) 650 13 00 Telefax: (+48-61) 650 13 50	United Kingdom GRUNDFOS Pumps Ltd. Grovebury Road Leighton Buzzard/Beds. LU7 8TL Phone: +44-1525-850000 Telefax: +44-1525-850011
Belorussia Представительство ГРУНДФОС в Минске 220090 Минск ул.Олешева 14 Телефон: (8632) 62-40-49 Факс: (8632) 62-40-49	India GRUNDFOS Pumps India Private Limited 118 Old Mahabalipuram Road Thorajapakkam Chamiers Road Chennai 600 096 Phone: +91-44 2496 6800	Portugal Bombas GRUNDFOS Portugal, S.A. Rua Calvet de Magalhães, 241 Apartado 1079 P-2770-153 Paço de Arcos Tel.: +351-21-440 76 00 Telefax: +351-21-440 76 90	U.S.A. GRUNDFOS Pumps Corporation 17100 West 118th Terrace Olathe, Kansas 66061 Phone: +1-913-227-3400 Telefax: +1-913-227-3500
Bosnia/Herzegovina GRUNDFOS Sarajevo Paromilnska br. 16, BiH-71000 Sarajevo Phone: +387 33 713290 Telefax: +387 33 231795	Indonesia PT GRUNDFOS Pompa Jl. Rawu Sumur III, Blok III / CC-1 Kawasan Industri, Pulogadung Jakarta 13930 Phone: +62-21-460 6909 Telefax: +62-21-460 6910/460 6901	Romania GRUNDFOS Pompe România SRL Bd. Biruintei, nr 103 Pantelimon county Ilfov Phone: +40 21 200 4100 Telefax: +40 21 200 4101 E-mail: romania@grundfos.ro	Usbekistan Представительство ГРУНДФОС в Ташкенте 700000 Ташкент ул.Усмана Носира 1-й тупик 5 Телефон: (3712) 55-68-15 Факс: (3712) 53-36-35
Brazil GRUNDFOS do Brasil Ltda. Rua Tomazina 106 CEP 83325 - 040 Pinhais - PR Phone: +55-41 668 3555 Telefax: +55-41 668 3554	Ireland GRUNDFOS (Ireland) Ltd. Unit A, Merrywell Business Park Ballymount Road Lower Dublin 12 Phone: +353-1-4089 800 Telefax: +353-1-4089 830	Russia ООО Грундфос Россия, 109544 Москва, Школьная 39 Тел. (+7) 095 737 30 00, 564 88 00 Факс (+7) 095 737 75 36, 564 88 11 E-mail grundfos.moscow@grundfos.com	Russia OOO Грундфос Россия, 109544 Москва, Школьная 39 Тел. (+7) 095 737 30 00, 564 88 00 Факс (+7) 095 737 75 36, 564 88 11 E-mail grundfos.moscow@grundfos.com
Bulgaria GRUNDFOS Pumpen Vertrieb Representative Office - Bulgaria Bulgaria, 1421 Sofia Lozenetz District 105-107 Arsenalki blvd. Phone: +359 2963 3820, 2963 5653 Telefax: +359 2963 1305	Italy GRUNDFOS Pompe Italia S.r.l. Via Gran Sasso 4 I-20060 Truccazzano (Milano) Tel.: +39-02-95838112 Telefax: +39-02-95309290/95838461	Serbia and Montenegro GRUNDFOS Predstavništvo Beograd Dr. Milutina Ivkovića 2a/29 YU-11000 Beograd Phone: +381 11 26 47 877, 11 26 47 496 Telefax: +381 11 26 48 340	Singapore GRUNDFOS (Singapore) Pte. Ltd. 24 Tuas West Road Jurong Town Singapore 638381 Phone: +65-6865 1222 Telefax: +65-6861 8402
Canada GRUNDFOS Canada Inc. 2941 Brighton Road Oakville, Ontario L6H 6C9 Phone: +1-905 829 9533 Telefax: +1-905 829 9512	Japan GRUNDFOS Pumps K.K. 1-2-3, Shin Miyakoda Hamamatsu City Shizuoka pref. 431-21 Phone: +81-53-428 4760 Telefax: +81-53-484 1014	Slovenia GRUNDFOS PUMPEN VERTRIEB Ges.m.b.H., Podružnica Ljubljana Blatnica 1, SI-1236 Trzin Phone: +386 1 563 5338 Telefax: +386 1 563 2098 E-mail: slovenia@grundfos.si	Slovenia GRUNDFOS PUMPEN VERTRIEB Ges.m.b.H., Podružnica Ljubljana Blatnica 1, SI-1236 Trzin Phone: +386 1 563 5338 Telefax: +386 1 563 2098 E-mail: slovenia@grundfos.si
China GRUNDFOS Pumps (Shanghai) Co. Ltd. 22 Floor, Xin Hua Lian Building 755-775 Huai Hai Rd, (M) Shanghai 200020 PRC Phone: +86-512-67 61 11 80 Telefax: +86-512-67 61 81 67	Korea GRUNDFOS Pumps Korea Ltd. 6th Floor, Aju Building 679-5 Yeoksam-dong, Kangnam-ku, 135-916 Seoul, Korea Phone: +82-2-5317 600 Telefax: +82-2-5633 725	Spain Bombas GRUNDFOS España S.A. Camino de la Fuentevilla, s/n E-28110 Algete (Madrid) Tel.: +34-91-848 8800 Telefax: +34-91-628 0465	Spain Bombas GRUNDFOS España S.A. Camino de la Fuentevilla, s/n E-28110 Algete (Madrid) Tel.: +34-91-848 8800 Telefax: +34-91-628 0465
Croatia GRUNDFOS predstavnštvo Zagreb Cebini 37, Buzin HR-10000 Zagreb Phone: +385 1 6595 400 Telefax: +385 1 6595 499	Latvia SIA GRUNDFOS Pumps Latvia Deglava biznesa centrs Augusta Deglava ielā 60, LV-1035, Riga, Tāl.: + 371 714 9640, 7 149 641 Faks: + 371 714 9646	Sweden GRUNDFOS AB Lunnagårdsgatan 6 431 90 Mölndal Tel.: +46-0771-32 23 00 Telefax: +46-31 331 94 60	Sweden GRUNDFOS AB Lunnagårdsgatan 6 431 90 Mölndal Tel.: +46-0771-32 23 00 Telefax: +46-31 331 94 60
Czech Republic GRUNDFOS s.r.o. Čapkovského 21 779 00 Olomouc Phone: +420-585-716 111 Telefax: +420-585-716 299	Lithuania GRUNDFOS Pumps UAB Smolensko g. 6 LT-03201 Vilnius Tel: + 370 52 395 430 Fax: + 370 52 395 431	Malaysia GRUNDFOS Pumps Sdn. Bhd. 7 Jalan Peguam U1/25 Glenmarie Industrial Park 40150 Shah Alam Selangor Phone: +60-3-5569 2922 Telefax: +60-3-5569 2866	Switzerland GRUNDFOS Pumpen AG Bruggacherstrasse 10 CH-8117 Fällanden/ZH Tel.: +41-1-806 8111 Telefax: +41-1-806 8115
Estonia GRUNDFOS Pumps Eesti OÜ Peterburi tee 44 11415 Tallinn Tel: + 372 606 1690 Fax: + 372 606 1691	Taiwan GRUNDFOS Pumps (Taiwan) Ltd. 7 Floor, 219 Min-Chuan Road Taichung, Taiwan, R.O.C. Phone: +886-4-2305 0868 Telefax: +886-4-2305 0878	Taiwan GRUNDFOS Pumps (Taiwan) Ltd. 7 Floor, 219 Min-Chuan Road Taichung, Taiwan, R.O.C. Phone: +886-4-2305 0868 Telefax: +886-4-2305 0878	
Finland OY GRUNDFOS Pumput AB Mestarintie 11 Piispankylä FIN-01730 Vantaa (Helsinki) Phone: +358-9 878 9150 Telefax: +358-9 878 91550			

BE ➤ THINK ➤ INNOVATE ➤

Being responsible is our foundation
Thinking ahead makes it possible
Innovation is the essence

XXXXXXX XXXX	GB
Repl. XXXXXXXX XXXX	